CONTENTS

UK

1. HOW TO CONNECT YOUR VIDEO RECORDER 4
How to connect your video recorder to the TV set 4
Connecting with a scart cable without 'Easy Link/NexTView' 5
Connecting without a scart cable 6
Connecting a decoder or other equipment 6

2. INSTALLING YOUR VIDEO RECORDER 7
Initial installation 7
Allocating a decoder 7
Manual TV channel search 8
Satellite receiver 8
Special installation functions 9
Automatic TV Channel Allocation (FOLLOW TV) 9
Automatic TV channel search (Autoinstall) 10
Monitor function 10
Sorting and clearing TV channels manually 10
Setting the time and date 11

3. IMPORTANT NOTES FOR OPERATION 12
General information 12
Saving energy 12
Emergency interrupt 12
The symbols on your video recorder display 12
Summary of user guide 13
User guide (OSD) 13

4. THE TAPE MANAGER (TM) 14
Adding a cassette to the Tape Manager 14
Searching for a title 15
Searching for a blank part of the tape 16
Editing the title 16
Copying the Tape Manager memory 17

5. PLAYBACK FUNCTIONS 18
Playing a cassette 18
Playing NTSC cassettes 18
Tape position indication 18
Searching for tape position with the picture (picture search) 18
Still picture/Slow motion 18
The JOG/SHUTTLE functions 19
The JOG/SHUTTLE functions on the remote control ... 19
Searching for tape position without the picture (wind and rewind) 19
Instant View 19
Automatic search for a tape position (index search) .. 19
Selecting the picture setting (SMART PICTURE) 19
Picture interference 20
Cleaning the video heads 20

6. MANUAL RECORDING 21
Recording without automatic switch-off 21
Recording with automatic switch-off (OTR one-touch-recording) 21
Protecting your recordings 21
Auto-assembling 21
Selecting the recording speed (SP or LP) 22
Automatic recording from a satellite receiver (SAT RECORDING) 22
Switching on 'Direct Record' 23

7. PROGRAMMED RECORDING (TIMER) 24
'VPS' (Video Programming System) and 'PDC' (Programme Delivery Control) 24
Programming a recording (with 'VIDEO Plus+') 24
Programming a recording (without 'VIDEO Plus+') 25
How to check or change a programmed recording (TIMER) 26
How to clear a programmed recording (TIMER) 26
'NexTView Link' 26

8. ADDITIONAL FUNCTIONS 27
Changing the TV system 27
Child lock 27
Switching the 'on-screen display' (OSD) on or off 28
Switching to 16:9 wide screen picture 28
Switching the remote control command 29
Continuous playback 29
Automatic switch-off (tuner mode) 30
Switching off the button illumination 30
Reducing picture disturbance ('optimizing the modulator') 31
Switching off the modulator 31
Using your video recorder remote control with your TV set 32
Manual audio control 32
Recording audio only 32
Audio dubbing 33
Selecting the sound track 33
Headphones volume 33
Synchronous editing (synchro-edit) 34
Connecting the video recorder and the camera recorder. 34
Starting synchro-edit 34
Variant 1, the video recorder is to control the camera recorder 35
Variant 2, the camera recorder is to control the video recorder 35
Setting the 'preroll time' 35

9. Before you call an engineer 36

10. GLOSSARY 37
Technical terms used 37

OPERATING INSTRUCTIONS IN BRIEF

The remote control



TAPE MANAGER **TapeManager**: To call up the Tape Manager

SMART **SMART**: To adjust the picture setting during playback

LIGHT **Button illumination** To switch the button illumination on the remote control on

MONITOR **TV monitor** : To switch between TV reception and VCR playback

STANDBY ⏻ **Switch off** : To switch off set, interrupt menu function, interrupt a programmed recording (TIMER)

EJECT ⏏ **Eject**: To eject a cassette

0-9 **Number buttons**: 0 - 9

SELECT **Select**: To select a function

TIMER ⏲ **TIMER**: To make a manual TIMER programming or to alter or clear a programmed TIMER

CLEAR (CL) **Delete** : To delete last entry or clear a programmed recording (TIMER)

MENU **Menu** : To call up or end main menu

OK **Store/Confirm**: To store or confirm entry

▲ **Select**: One line up

► **Playback** : To play a recorded cassette

◄ **Select**: Cursor left

◁◁ **Rewind** : During STOP and STANDBY: rewind, during PLAYBACK: reverse scanning

▶▷ **Forward wind**: During STOP and STANDBY: forward wind, during PLAYBACK: forward scanning

► **Select**: Cursor right

■ **Pause/Stop**: To stop the tape, except while a TIMER-recording is being made

▼ **Select**: One line down

INDEX ▶| **Index search**: In combination with

COUNTER **Counter**: To select display of tape positon

PROG. − **Select**: To select a programme number

PROG. + **Select**: To select a programme number

STILL/JOG ON ▶|◀ **Still picture/JOG on**: To stop the tape and show a still picture/switch on the 'JOG' function

RECORD/OTR ● **Record**: To record the programme selected

⊙ **JOG**: During STILL picture, select single picture with the inner dial (jog)

-⊙+ **Rotary control**: Turn left: during STOP and STANDBY: rewind, during PLAYBACK: reverse scanning
Turn right: during STOP and STANDBY: wind, during PLAYBACK: forward scanning

Additional TV functions

◿+ **TV volume**: TV volume up

◿− **TV volume**: TV volume down

TV ⏻ **TV Switch off** : To switch off the TV

TV 🔇 **TV sound off** : To switch the sound on or off

TV AV To switch the TV to Audio/Video in-socket

TV + **TV Programme number**: TV programme number up

TV − **TV Programme number**: TV programme number down

Front of the set



STANDBY ⏻ **Standby** : To switch off, interrupt a function, interrupt a programmed recording (TIMER)

MANUAL **Manual sound control** : To switch between automatic sound control and manual sound control

PROGRAMME ▲ **Programme number up**: To select the next programme number

PROGRAMME ▼ **Programme number down**: To select the previous programme number

RECORD ● **Record**: To record the programme selected

EJECT ▲ **Eject**: To eject a cassette

STOP ■ **Pause/Stop**: To stop the tape, except during programmed recording (TIMER)

PLAY ► **Playback** : To play a recorded cassette

-⊙+ **Rotary control**: Turn left: during STOP and STANDBY: rewind, during PLAYBACK: reverse scanning
Turn right: during STOP and STANDBY: wind, during PLAYBACK: forward scanning

⊙ **JOG**: During STILL picture, select single picture with the inner dial (jog)

STILL/JOG ON ▶◀ **Still picture**: To stop the tape and show a still picture

Behind the flap at the lefthand corner on the front:

L AUDIO R **Audio input socket left/right** : To connect a camera recorder or video recorder (programme number 'E3')

VIDEO **Video input socket** : To connect a camera recorder or video recorder ('E3')

SYNCHRO EDIT **EDIT input socket** : To connect a suitable camera recorder

PHONES **Headphones socket**: To connect headphones

MIC. **Microphone input socket**: To connect a microphone for dubbing (programme number 'MIC')

Back of the set



~ **Mains socket**: To connect the mains cable

AUX IN L R **Audio input socket, left/right** : To connect a HiFi-set (programme number 'AUX')

AUX OUT L R **Audio output socket, left/right** : To connect a HiFi-set

EXT.2 AV 2 **Scart socket 2**: To connect a satellite receiver, decoder, video recorder, etc. (programme number 'E2')

EXT.1 AV 1 **Scart socket 1**: To connect the TV set (programme number 'E1')

Aerial input socket: To connect the aerial cable

TV **Aerial output socket**: To connect the TV set

OPERATING INSTRUCTIONS PHILIPS VR900/07

UK

Congratulations! You now own one of the most sophisticated and simple-to-use video recorders (VCR) on the market. With this VCR you can record and play VHS-standard cassettes.

Please take the time to read this operating manual before using your video recorder.

Safety instructions and other notes

Danger: High voltage!
Do not remove the top cover as there is a risk of an electrical shock!

The video recorder does not contain any components that can be repaired by the customer. When the appliance is connected to the power supply there are some components that are constantly operational. To switch off the video recorder completely you must disconnect it from the power supply.

Make sure that air can circulate freely through the ventilation slots on the video recorder.

Make sure that no objects or liquids enter the video recorder. If liquid is spilt into it, disconnect the video recorder immediately from the power supply and call the After-sales Service for advice.

The video recorder should **not be used immediately after transportation** from a cold to a hot area or vice versa, or in conditions of extreme humidity.
After unpacking the video recorder, it should be allowed to **acclimatize for at least three hours** before installation.

These operating instructions have been printed on nonpolluting paper.

Deposit old batteries at the relevant collection points.

Please make use of the facilities available in your country for disposing of the packaging of the video recorder in a way that helps to protect the environment.

This electronic equipment contains many materials that can be recycled. Please inquire about the possibilities for recycling your old set.

VIDEO Plus+ and PlusCode are registered trademarks of Gemstar Development Corporation. The VIDEO Plus+ system is manufactured under licence from Gemstar Development Corporation.

So that you can identify your machine in the event of theft, enter the serial number (PROD.NO) here. The serial number is printed on the type plate fixed at the rear of the set.

MODEL NO.	**VR900/07**
PROD.NO:	

This product complies with the requirements of the Directive 73/23/EEC + 89/336/EEC + 93/68/EEC.

Interference

The Department of Trade and Industry operates a Radio Investigation Service to help TV licence holders improve reception of BBC and ITC programmes where these are being spoilt by interference.
If your dealer cannot help, ask at a Main Post Office for the booklet 'How to Improve Television and Radio Reception'.

Technical information

Measurements in cm (W / H / D): 43.5 / 9.3 / 29.0
Power consumption (Standby) : less than 4W (Saving energy mode)
Voltage : 220-240V/50Hz
Number of heads : 4 Video / 2 Audio
Winding time: approx. 90 seconds (Cassette E-180)
Recording/Playback time :SP (Standard Play) 4 hours (Cassette E-240) / LP (Long Play) 8 hours (Cassette E-240)
Headphones : Output resistance less than 120 Ohms maximum output voltage more than 2.6V at 120 Ohms
Microphone output level: less than 0.3mV

List of accessories

- Operating instructions
- Remote control and batteries
- Aerial cable
- Mains cable
- Quick install quide
- Scart cable (AV-Euro cable)
- Audio cable (CINCH cable)

Special functions on your video recorder

Crystal Clear Video

This system ensures that your picture will be of the best possible quality. This is made possible by a combination of Philips' very latest technologies: Natural Colour, Smart Picture, Digital Studio Picture Control and laser-cut video heads.

Natural Colour

Natural Colour produces detailed pictures in clear colours.

Digital Studio Picture Control

Philips has developed a system which produces the best possible playback quality. It reduces disturbance on old, worn video cassettes, and emphasises the detail on very good quality cassettes.

Smart Picture

This function allows you to save the playback settings that suit you best. Select your own personal settings for the type of film you are currently watching.

TAPE MANAGER

By pressing the button once you obtain both simply and conveniently an overview of your entire video archive. You never need to search again because the tape manager stores all recordings and knows on which cassette they are located.

easyLINK

Philips provides the best possible connection between your video recorder and other home cinema equipment.

Plug & Play

When you connect your video recorder to your television and plug it into the mains, you will be welcomed with an OSD picture. All you have to do is follow the instructions in the "intelligent help line" for the next step. Enjoy the Automatic TV channel search/save function and the automatic time adjustment.

Multibrand TV control

You can operate the main functions on your television using your video recorder remote control, even if your television is not a Philips one.

2000

We guarantee that your video recorder will switch to the new millennium with no problems whatsoever.

Automatic Satellite Recording

Recordings made on your video recorder can be controlled by an external satellite receiver.

Follow TV

This function automatically transfers all the television channel settings onto your video recorder.

Direct Record

Your video recorder can ascertain which channel is currently playing on your television and record from it at the touch of a button.

VIDEO Plus+

Simple programming system for video recorders. Makes programming as easy as making a telephone call. Simply enter the programme code which you will find in your listings magazine.

TURBO DRIVE

The precision tape drive from Philips with short rewind times and automatic tape length recognition.

1. HOW TO CONNECT YOUR VIDEO RECORDER

Important for the United Kingdom

This machine is fitted with an approved moulded 13 Amp plug. To change a fuse in this type of plug, please follow these instructions.

1 Take off the fuse cover and take out the fuse.

2 Put in a new fuse which should be a BS1362 3A, A.S.T.A. or BSI approved type.

3 Refit the fuse cover.

If the plug fitted is not suitable for your socket, cut it off and fit another type.
If the plug you fit contains a fuse, it should be a 3Amp fuse. If you fit a plug which does not need a fuse, make sure the fuse on your fuse box is not greater than 5 Amps.

Note: Please destroy the plug you have cut off so that it cannot be used in a 13 Amp socket somewhere else.

How to connect a plug
The wires in the lead from the video recorder are coloured as follows.
* Blue - 'neutral' ('N').
* Brown - 'live' ('L').

4 Connect the blue wire to the terminal in the plug which is marked with the letter 'N' or coloured black.

5 Connect the brown wire to the terminal in the plug which is marked with the letter 'L' or coloured red.

6 Do not connect either of the wires to the terminal in the plug which is marked with the letter 'E', the symbol ⏚ or coloured green or green and yellow.

Before you refit the plug cover, make sure that the grip at the bottom of the plug is clamped over the plastic cover of the lead, not just over the two wires.

How to connect your video recorder to the TV set

We recommend the use of a scart cable. This will give you the best picture and sound quality.



When you install your video recorder for the first time, please read:

- ☐ The section 'Connecting with scart cable and Easy Link/NexTView', when your TV set is equipped with 'Easy Link/NexTView'.
- ☐ The section 'Connecting with scart cable without Easy Link/NexTView', when your TV set is not equipped with 'Easy Link/NexTView'.
- ☐ The section 'Connecting without a scart cable', if you are not using a scart cable.

Connecting with scart cable and 'Easy link/NexTView'

easy LINK NEXTVIEW

With the function 'Easy Link/NexTView', your video recorder can exchange information with the television (see instruction manual TV set.). With 'Easy Link/NexTView' the TV channels from the TV will automatically be loaded.



1 Switch off the TV set.

2 Remove the aerial cable plug from your TV set and insert it into the ⊓⊓ socket at the back of the video recorder.

3 Plug one end of the aerial cable provided into the TV socket on the video recorder and the other end into the aerial input socket on your TV set.

4 Plug one end of the special scart cable provided into the EXT.1 AV 1 scart socket at the back of the video recorder and the other end into the scart socket on your TV set (see instruction manual TV set).

5 Switch on the TV set.

6 Insert one end of the mains cable into the mains socket ~ at the back of the video recorder and the other end into the wall socket.

7 The video recorder will automatically load all TV channels stored on your TV, in the same sequence. This may take several minutes.
When all information has been copied, the following text will appear on the TV screen: 'EASY LINK LOADING COMPLETE'.

8 Check if time and date are correct. Read the section 'Setting Time/Date' in the chapter 'INSTALLING YOUR VIDEO RECORDER'.

Connecting with a scart cable without 'Easy Link/NexTView'



1 Switch off the TV set.

2 Remove the aerial cable plug from your TV set and insert it into the ⊓⊓ socket at the back of the video recorder.

3 Plug one end of the aerial cable provided into the TV socket on the video recorder and the other end into the aerial input socket on your TV set.

4 Plug one end of the scart cable into the EXT.1 AV 1 scart socket at the back of the video recorder and the other end into the scart socket on your TV set (see instruction manual TV set).

5 Switch on the TV set.

6 Insert one end of the mains cable into the mains socket ~ at the back of the video recorder and the other end into the wall socket.

7 If your TV set **automatically switches** to programme number e.g.: 'EXT', '0', or 'AV', this text will appear on the TV screen:



i If your TV set does not switch to programme number e.g.: 'EXT', '0', or 'AV' automatically, select the programme number for the video recorder manually (see instruction manual TV set).

8 Then read 'Initial installation' in chapter 'INSTALLING YOUR VIDEO RECORDER'.

Connecting without a scart cable



1 Switch off the TV set.

2 Remove the aerial cable plug from your TV set and insert it into the socket at the back of the video recorder.

3 Plug one end of the aerial cable provided into the socket on the video recorder and the other end into the aerial input socket on your TV set.

4 Insert one end of the mains cable into the mains socket at the back of the video recorder and plug the other end into the wall socket.

5 Switch on your TV set and select the programme number that you have chosen for video playback (see instruction manual TV set).

6 Tune the TV set until this picture appears.

The video recorder will now be sending a welcoming text on channel 35 or 583MHz.



7 When the TV has been tuned read the paragraph 'Initial installation' in the chapter 'INSTALLING YOUR VIDEO RECORDER'.

Connecting a decoder or other equipment

You can connect additional equipment to the EXT.2 AV 2 socket. For example: a decoder, a satellite receiver or a camera recorder.
You can connect a HIFI-stereo set to the sockets AUX OUT L R (audio output left/right) and AUX IN L R (audio input left/right).



2. INSTALLING YOUR VIDEO RECORDER

UK

Initial installation

1 Open up the battery compartment of your remote control and place the batteries in it as shown in the picture.



2 Close the battery compartment.

3 Confirm the picture on the TV screen with the OK button on the remote control.

4 If you have connected the aerial to the video recorder, press the OK button. 'Autoinstall' starts. This picture will appear on the screen:



Wait until all TV channels have been found. This can take several minutes.

5 When 'AUTOINSTALL' is complete, 'AUTOINSTALL COMPLETE' will appear on the TV screen.

6 To end, press the MENU button.
The initial installation is now complete.
Check the time and date. Please read 'Setting the time and date' in this chapter.

i If you have connected a decoder, you must install it as described in the next section.

i If you have connected a satellite receiver, please read the section 'satellite receiver'.

Allocating a decoder

Some TV stations will send coded TV channels, that you can only watch when you use a decoder. You can connect such a decoder (descrambler) to your video recorder. With the following function, the connected decoder will automatically be activated for the TV programme you want to watch.

i With 'Connecting with scart cable and 'Easy Link/NexTView' the decoder must be activated for the TV set.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Choose the television channel on which you wish to use the decoder with the PROG.+ or PROG.– buttons on the video recorder or the number buttons 0-9 on the remote control.

3 Press the MENU button on the remote control. The main menu will appear.

4 Select the line 'INSTALLATION' with the ▼ or ▲ button and confirm with the ▶ button.

5 Select the line 'MANUAL SEARCH' with the ▼ or ▲ button and confirm with the ▶ button.



6 Select the line 'DECODER' with the ▼ or ▲ button.

7 Select function 'ON' with the ◀ or ▶ button. When you select 'OFF', the function will be switched off.

8 Confirm with the OK button.

9 To end, press the MENU button.
Your decoder has now been allocated to this TV channel.

i When the function is switched on, 'DEC' appears in the display.



Manual TV channel search

In certain cases the 'Automatic TV channel search' may not be able to find all of the TV channels (e.g. coded TV channels). In that case, use this manual method to set the channels.

> With 'Connecting with scart cable and 'Easy Link/NexTView' the videorecorder automatically takes the TV channels from the TV set. This is why some lines are not functional.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button. The main menu appears.

3 Select the line 'INSTALLATION' with the ▼ or ▲ button and confirm with the ▶ button.

4 Select the line 'MANUAL SEARCH' with the ▼ or ▲ button and confirm with the ▶ button.



5 In the line 'CHANNEL/FREQ.', select the display for:
'FREQ.': frequency
'CH': channel
'S-CH': special channel

6 If you know the frequency or channel of the desired TV channel, you can enter the data in line 'ENTRY/SEARCH' with the digit buttons 0-9.

> If you don't know the frequency or channel of the TV channel of your choice, press the ▶ button to start the channel search.

7 In the line 'PROGRAMME NUMBER' select the programme number you want e.g.: '01' with the ◀ or ▶ button.

8 If you want to change the TV channel name, press the ▶ button in line 'TV CHANNEL NAME'.

☐ Select the character you want to change with the ◀ or the ▶ button. Change the character with the ▼ or the ▲ button. Select the next character in the same way.

☐ Keep pressing the ▶ button until the cursor disappears.

9 In the line 'NICAM', select funtion 'ON' or 'OFF' with the ▶ or ◀ button.

10 If you want to change the automatic tv channel setting, select the line 'FINE TUNING'.
With the ◀ or ▶ button you can vary the automatic tv channel setting. **Important:** This re-tuning is only necessary and useful in **special cases**, e.g.: when there are stripes on the picture with cable-TV systems.

11 Press the OK button to store the TV channel.

> If you want to search for further TV channels, start again at step 6.

12 To end, press the MENU button.

Satellite receiver

You can receive channels from the satellite receiver via the scart socket EXT.2 AV 2.
To do this, select the channel number 'E2' by pressing the buttons PROG.+ or PROG.−. You will have to select the channels to be received by the satellite receiver on the receiver itself.

Special installation functions

You can select one of the following installation functions in order to adapt the video recorder to your own specific requirements.

Automatic TV Channel Allocation (FOLLOW TV)

With this function the video recorder maintains the same channel sequence as on the TV set, in case you connected your videorecorder to a TV set **without scart cable**. This only functions if the video recorder (socket EXT.1 AV 1) and the TV set are **connected with a scart cable**.

i Additional equipment connected to socket EXT.2 AV 2 must be **switched off**.

i With 'Connecting with scart cable and 'Easy Link/NexTView', this function will start the data transfer.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button. The main menu appears.

3 Select the line 'INSTALLATION' with the ▼ or ▲ button and confirm with the ▶ button.



4 Select the line 'FOLLOW TV' with the ▼ or ▲ button and confirm with the ▶ button. Take notice of the message on the TV screen.

5 Press the OK button. 'TV01' appears in the video recorder display.

6 Select programme number '1' **on the TV set**.

7 Confirm with the OK button on the video recorder-remote control. The video recorder compares the TV channels on the TV set and the video recorder. If the video recorder found the same TV channel as the TV set, then it stores it at 'P01'.

i When 'NOTV' (no signal from TV set) appears in the display, the TV channels can not be allocated automatically. In this case, read paragraph: 'Manual TV channel allocation'.

8 Wait until e.g.: 'TV02' appears.

9 Select the next programme number, e.g.: '2' **on the TV set**.

10 Confirm with the OK button on the video recorder-remote control.

i If you have allocated the wrong TV channeL, you can go back one step with the ◀ button.

11 Repeat steps 8 to 10 until all TV channels have been allocated.

12 To end, press the MENU button.

Automatic TV channel search (Autoinstall)

The video recorder will search for all TV channels. It stores TV channels found in the following sequence: BBC 1, BBC 2, ITV, CH 4, CH 5, SKY, others.

> If you want to start the automatic TV channel search again, then follow the instructions below.

1. Switch on the TV set. If required, select the programme number for the video recorder.
2. Press the MENU button on the remote control. The main menu will appear.
3. Select the line 'INSTALLATION' with the ▼ or ▲ button and confirm with the ▶ button.
4. Select the line 'AUTOINSTALL' with the ▼ or ▲ button.
5. Press the ▶ button. The 'Automatic TV channel search' starts.



6. When Autoinstall is complete, 'AUTOINSTALL COMPLETE' will appear on the display.
7. The time and date information have been set.

How to search for a TV channel manually, you can read in the section 'Manual TV channel search'.

Monitor function

You can switch backwards and forwards between TV picture and video recorder picture with the MONITOR button. But this only works when you use a scart cable to connect the video recorder to your TV set and if your TV set responds to this switch-over.

Sorting and clearing TV channels manually

You can assign any programme number to a TV channel that you have stored and you can also delete unwanted TV channels.

> With 'Connecting with Easy Link/NexTView' the video recorder automatically loads the TV channels from the TV set. That is why you cannot select this manual function.

1. Switch on the TV set. If required, select the programme number for the video recorder.
2. Press the MENU button. The main menu appears.
3. Select the line 'INSTALLATION' with the ▼ or ▲ button and confirm with the ▶ button.
4. Select the line 'TV CHANNEL ALLOCATION' with the ▼ or ▲ button and confirm with the ▶ button.



5. With the ▼ or ▲ button, select the TV channel to which you want to allocate a programme number (starting with 'P01').
6. To confirm, press the ▶ button.

> If you want to delete a TV channel, press the CLEAR (CL) button.

7. With the ▼ or ▲ button, shift the TV channel to the programme number you wish to allocate to this TV channel and press the ◀ button. The video recorder will add the TV channel.
8. Repeat steps 5 to 7 until you have allocated a programme number to all TV channels.
9. To store, press the OK button.
10. To end, press the MENU button.

Setting the time and date

If a TV channel which transmits TXT/PDC is stored under programme number 'P01', time and date will automatically be taken from the TXT/PDC information.

If the time in the video recorder display is not correct or if '--:--' appears in the display, please set the clock manually.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button on the remote control. The main menu will appear.

3 Select the line 'INSTALLATION' with the ▼ or ▲ button and confirm with the ▶ button.

4 Select the line 'TIME/DATE' with the ▼ or ▲ button and confirm with the ▶ button.



5 Check the time in line 'TIME'. If required, please change the time with the 0-9 buttons on the remote control.

6 Check 'YEAR', 'MONTH' and 'DATE' in the same way. Switch between the fields with the ▼ or ▲ button.

7 Confirm the new information with the OK button.

8 To end, press the MENU button.

3. IMPORTANT NOTES FOR OPERATION

General information

- You can switch on with the ■ button, the 0-9 buttons or by putting in a cassette.
- If you do not use the video recorder for a few minutes, it will switch to standby automatically. Please read the section 'Automatic switch-off' in chapter 'ADDITIONAL FUNCTIONS'.
- If you have switched the video recorder off with the STANDBY ⏻ button, the time will show in the display, for instance , '18:00'.
  If the clock has not been set, '- - : - -' will appear.
- Keep your video recorder connected to the mains at all times to ensure that programmed recordings can be made and that the television works normally.
- If the video recorder is not plugged into the mains, it will usually store TV channels and timer information for a year, and date information for seven hours.

Saving energy

There are two ways to switch to standby.
Switching to standby with clock display: Switch to standby using the STANDBY ⏻ button. The time will be displayed.
To save energy: Press the STANDBY ⏻ button twice. The time will disappear from the display.

Emergency interrupt

You can use the STANDBY ⏻ button on the video recorder or the remote control to interrupt any function.
So if you are having operating problems, you can just interrupt the function and start again.
And you can practise operating your set without any worries. No matter which buttons you press, you cannot damage it.

The symbols on your video recorder display

These symbols can light up on your video recorder display:

VPS/PDC	Video programming system / programme delivery control: when a VPS or PDC code is being transmitted.
	This is where the current operating mode is shown as a symbol.
●	When you are recording a progamme.
⏻	When you have programmed a recording or when a programmed recording is being made.
LP	When you play a tape that has been recorded in LP (Long Play).
	When you have put a cassette in the video recorder.
	When you have switched on the child lock.
	When a satellite recording has been programmed.
DEC	When a decoder has been allocated to the TV channel you have currently selected.
	Display of programme number / tape position / channel name / function.
h	Tape position in hours.
m	Tape position in minutes.
s	Tape position in seconds, but only if the display mode 'COUNTER' has been selected.
HiFi	When you play a cassette that has been recorded with hifi sound, or when a hifi sound is transmitted.
NICAM	When the video recorder recognizes a Nicam audio signal.
L R	This shows the sound track you have selected.
	This shows the audio control (L-left channel/R-right channel).

Summary of user guide

The OSD menu offers the following functions. More details on each can be found in the appropriate chapter.



User guide (OSD)

The OSD (On-screen display) shows the various functions in the form of a menu on the television screen. You can then choose the settings you require. There is a summary of the menus on this page. The main button functions are displayed in a help line along the bottom of the screen.

- ☐ **To call up the menu:** With the MENU button.
- ☐ **To select a line:** With the ▼ or ▲ button.
- ☐ **To make a selection in a line:** With the ◄ or ► button.
- ☐ **To enter or change your selection:** With the 0-9, ◄ or ► button.
- ☐ **To cancel:** With the MENU button.
- ☐ **To save:** With the OK button.
- ☐ **To confirm:** With the ► button.
- ☐ **To close the menu:** With the MENU button.

4. THE TAPE MANAGER (TM)

With the tape manager (TM) you have a complete overview of all recordings made with this video recorder.
Moreover, with the tape manager (TM) you have fast and simple access to every **recording made** with this video recorder.



We recommend reading the section entitled 'Adding a cassette to the Tape Manager' so as to keep your preparations to a minimum.

Don't use a Tape Manager cassette for recording on other video recorders.

Adding a cassette to the Tape Manager

Only new (blank) cassettes can be added to the Tape Manager. A cassette that has been recorded on can not be added to the Tape Manager.

With this video recorder however, new recordings can be made as often as you wish on a cassette added to the tape manager. The titles of these recordings are stored automatically in the tape manager.

1 Switch the television on. Select the channel number for the video recorder if necessary.

2 Insert a new, blank cassette in the video recorder.
The video recorder will briefly check the cassette inserted. 'CHECKING CASSETTE' will appear on the screen.

If the cassette is new (blank), will appear on the screen.



If the cassette has already been registered in the Tape Manager, the cassette number and all the titles stored on this cassette will appear on the screen.

If you put a cassette into the machine that has been recorded on, but has not been registered in the Tape Manager, no information will appear on the screen.

3 Confirm with the OK button.

4 The cassette number will be added to the Tape Manager will appear in the display.



The cassette number will now be displayed and the cassette will be ejected automatically.

5 The cassette is now stored in the tape manager under the displayed cassette number.
Write the cassette number that is shown on the screen on your cassette.

You can store up to 150 cassettes. You can store a maximum number of 210 titles in the Tape Manager.

Searching for a title

You can easily search for the title of a recording stored in the Tape Manager. When the video recorder finds the title, playback will start automatically at the beginning of the recording searched for.

1 Press the TAPE MANAGER button on the remote control.

2 Select the line 'FIND A TITLE'.

3 Confirm with the ▶ button.

i If you have inserted a cassette that is not stored in the Tape Manager you can choose between the 'THIS CASSETTE' or 'TM-MEMORY' lines by pressing the PROG.– button.

i If you confirm 'THIS CASSETTE' with the ▶ button, the video recorder will check the cassette inserted. This can take some time. A list of all recordings on this cassette will appear on the screen. Continue at step 5 .

i If you confirm 'TM-MEMORY' with the ▶ button, continue at the next step.

4 Using the ▶ or ◀ button, you can easily see the contents of the various cassettes in line 'CASSETTE NUMBER'.

i A list of the titles on the selected cassette will be displayed on the screen.



i **Explanation:**
XXX = cassette number
BBC NEWS = title
0:25 = Length of the recording
L = Long Play recording

5 Press the PROG.+ or PROG.– button to select the title you require.

6 Confirm with the OK button.

i If the cassette is not in the video recorder, for example, 'INSERT CASSETTE NUMBER XXX' will appear on the screen.
Insert the corresponding cassette into the video recorder.

7 The video recorder will search for the desired title and will start playback automatically.

Searching for a blank part of the tape

To make a recording, you can search for a blank part of the tape (at least 1 minute of blank tape), for example, after an existing recording on the tape.
This only works with cassettes with cassettes which have been stored in the Tape Manager.

1 Press the TAPE MANAGER button on the remote control.

2 Select the line 'FIND A TITLE' with the PROG.+ or PROG.– button. 'FIND A TITLE'

3 Confirm with the ▶ button.

i If you have put a cassette in the machine which is not registered in the Tape Manager, select the line 'TM-MEMORY' with the PROG.– button.

4 In the line 'CASSETTE NUMBER' you can select a different cassette number with the ▶ or ◀ button.

i A list of the titles on the selected cassette will be displayed on the screen.



5 Select the title 'EMPTY' with the PROG.+ or PROG.+ button.
The time remaining to the end of the cassette is displayed next to the title 'EMPTY'.

6 Confirm with the OK button.

i If the required cassette has not been inserted into the video recorder, for example, 'INSERT CASSETTE NUMBER XXX' will appear on the screen.
Put the required cassette in the machine.

7 Once the video recorder has found the position on the tape it will stop automatically.

Editing the title

The title of a recording is automatically recorded if it is broadcast by the television channel. Otherwise the date and time of the recording are stored as the title. You can edit the title according to your own personal wihses.

1 Press the TAPE MANAGER button on the remote control.

2 Select the 'EDIT A TITLE' line. Confirm with the ▶ button. A listing of all the recordings on the cassette in the machine will be displayed on the screen.

i In line 'CASSETTE NUMBER' you can select a different cassette number with the ▶ or ◀ button.



3 Select the title you require with the PROG.+ or PROG.– button.

4 Press the ▶ button.

5 Select the symbol you want to change with the ▶ or ◀ button.

6 Change the symbol at the symbol position with the PROG.+ or PROG.– button.

7 Save the new title with the OK button.

If you want to change more titles, repeat step 3 through 6 .

Removing a cassette number

Every cassette is stored with a number in the Tape Manager. You can delete this cassette number from the Tape Manager, so that you can use this cassette for special recording functions (for instance, synchro edit or dubbing). You can delete cassette numbers that you don't need anymore to create space for new cassettes.

1 Press the TAPE MANAGER button on the remote control.

2 Select the line 'REMOVE A CASSETTE NR.'. Confirm by pressing ▶.

3 Select the cassette you require by pressing the ◀ or ▶ button and press OK.



4 Confirm the cassette number with the OK button.

i The word 'CASSETTE NUMBER XXX REMOVED FROM MEMORY' will appear on the screen when the cassette number has been removed.

i The cassette will now be removed from the Tape Manager.

Copying the Tape Manager memory

If you cannot or do not want to use your video recorder (VCR A) any more, you can transfer the Tape Manager memory to another video recorder (VCR B).

i Video recorder (VCR B) must also be equipped with the Tape Manager. The Tape Manager of VCR B must be empty.

1 Switch off VCR A and VCR B with the STANDBY ⏻ button. Please note, that no cassette is inserted in either one of the machines.

2 Connect the EXT.1 AV 1 socket on VCR A to the EXT.1 AV 1 socket on VCR B.



3 On VCR A, press the RECORD ● and PROGRAMME ▼ buttons at the same time.

4 On VCR B, press the PLAY ► and PROGRAMME ▼ buttons at the same time.
'TM' will appear in the display.

i A search symbol will appear in the display while the information is being copied. This may take a few minutes.

5 When the transfer is finished, the display will read 'OK'.

i If 'NO E' appears in the display on VCR B, there are already some cassettes stored in the Tape Manager. To end, press the STANDBY ⏻ button.

i If 'NO D' appears in the display on VCR B, there are no cassettes stored in the Tape Manager on VCR A. Finish with the STANDBY ⏻ button.

i If 'ERR.' appears in the display on VCR B, this means that an error was detected during the information transfer. Repeat the transfer starting with step 1 .

6 When the transfer is finished, both video recorders will switch off automatically. Remove the scart cable.

5. PLAYBACK FUNCTIONS

Playing a cassette

1 Put a cassette into the cassette slot. '📼' will appear on the display.



The cassette is being checked. Wait until the search symbol in the display has gone out. You can find more information on the Tape Manager in the chapter 'The Tape Manager (TM)'.

2 Press the ► button.

3 To stop, press the ■ button.

4 To eject the cassette, press the EJECT ▲ button on the video recorder.
To eject a cassette, you can also use the EJECT ▲ button on the remote control

Some hired cassettes may have a poor picture or poor sound quality. This is not a fault in your machine. Please read the section 'Selecting the picture setting (SMART PICTURE)', or 'Eliminating picture interference'.

Some functions switch off automatically after a while (for example, pause, still picture, picture search). This helps to protect the cassette and avoids wasting power.

Playing NTSC cassettes

With this set you can playback cassettes that have been recorded on another video recorder in the NTSC standard (for example, American cassettes). But this only works for PAL-television sets which are suitable for a picture frequency of 60 Hz.
When you play an NTSC cassette '60HZ' will appear on the display.

Some special features (for example, still picture) are not possible while you are playing an NTSC cassette.

Tape position indication

By pressing the OK button, you can show the present tape position on the TV screen.

1 During playback press the COUNTER button.

2 Select one of the following options with the COUNTER button:
'TIME USED' to indicate the time used on the tape
'TIME LEFT' to indicate the time left on the tape
'COUNTER' to indicate the actual position on the tape

To reset the tape position to '0:00:00', press the CLEAR (CL) button.

This video recorder will automatically recognise the length of the tape.

When you put in a cassette, the video recorder must first calculate the playing time for 'TIME USED' or 'TIME LEFT'. Therefore, the display first shows '⏲' and then shows the playing time after the tape has been running for a few seconds.

If there is no recording on the tape and you have selected 'COUNTER', the counter will stop.

Searching for tape position with the picture (picture search)

1 While a cassette is playing, press the ◁◄ (reverse) or ►▷ (forward) button once or several times.

2 To stop a certain place on the tape, press the ► button.

During picture search, the picture quality may not be so good and there will be no sound.

Still picture/Slow motion

1 Press the STILL/JOG ON ▶|◀ button. A still picture will appear on the screen.

2 Each time you press STILL/JOG ON ▶|◀ again, the picture will move on one step.

3 When you hold the STILL/JOG ON ▶|◀ button, the tape will be played in slow motion.

4 When you press the ►▷ button several times, you have a choice of several playback speeds.
During slow motion there will be no sound.

The JOG/SHUTTLE functions

You will find a large rotary knob (Shuttle) [-◎+] on the video recorder and on the remote control.

1. Switch the function on with the [STILL/JOG ON ▶◀] button on the remote control or the [STILL ▶◀] button on the video recorder.
   You will see a still picture.
2. You can select the next single frame forwards or backwards with the jog button on the remote control or the video recorder.
3. Turning the inner disc continuously to the right or to the left switches to slow motion.
4. The outer (shuttle) ring enables you to select different tape speeds for picture search.

The JOG/SHUTTLE functions on the remote control

You will find a large rotary knob (Shuttle) [-◎+] on the remote control.

1. Switch the function on with the [STILL/JOG ON ▶◀] button on the remote control.
   You will see a still picture.
2. Use the inner disc (jog) on the remote control to select the next or previous still picture.
3. Turning the inner disc continuously to the right or to the left switches to slow motion.
4. The outer (shuttle) ring enables you to select different tape speeds for the picture search.

Searching for tape position without the picture (wind and rewind)

1. Stop the tape with the [■] button.
2. Press the [◁◀] (reverse) or [▶▷] (forward) button. If you want to carry out this function on your video recorder, turn the large knob (shuttle) [-◎+] to the left or to the right.
3. To stop a certain place on the tape, press the [■] button.

Instant View

With this function you can switch to picture search during wind and rewind.

1. If you hold the [◁◀] (rewind) or [▶▷] (wind) button during wind or rewind, you will switch to picture search.

   If you want to carry out this function on your video recorder, turn the large knob to the left or to the right while you wind or rewind the tape.
2. When you release the button, the video recorder will automatically switch back to rewind or wind.

Automatic search for a tape position (index search)

At the start of each recording, the video recorder will write an index code on the tape.

1. Press the [INDEX ▶|] button and then the [▶▷] button to select the next code mark or the [◁◀] button for the previous code mark.
2. When the video recorder finds the code mark, it will automatically switch to play.

Selecting the picture setting (SMART PICTURE)

You can change the picture setting while a tape is playing.

1. Press the [SMART] button. This will show the current picture setting.
2. Press the [SMART] button again to select the picture setting of your choise.
   'NATURAL': for all types of movies (natural picture)
   'DISTINCT': for fast movement, sport (detailed picture)
   'SOFT': for hired tapes (interference is suppressed)
   'SHARP': for cartoons (sharp picture)

   This picture setting will not change until you eject the cassette.

Picture interference

If the picture quality is poor when you play a cassette, please follow these instructions.

Tracking during playback

1. During playback, press the MENU button.
2. Select the line 'PLAY FUNCTIONS' with the ▼ or ▲ button and confirm with the ▶ button.
3. Select the line 'MANUAL TRACKING' with the ▼ or ▲ button.
4. Hold the ◀ or ▶ button until the playback quality is at its best.
5. Confirm with the OK button.
6. To end, press the MENU button. This setting will remain until you remove the cassette.

Tracking during still picture

If the still picture vibrates vertically, you can improve the still picture as follows:

1. During still picture, press the MENU button.
2. Select the line 'PLAY FUNCTIONS' with the ▼ or ▲ button and confirm with the ▶ button.
3. Select the line 'VERTICAL STABILITY' with the ▼ or ▲ button.
4. Hold the ◀ or ▶ button until the picture quality is at its best.
5. Confirm with the OK button.
6. To end, press the MENU button.

   Please note, however, that interference may still occur with poor quality cassettes.

Cleaning the video heads

If horizontal lines appear on the screen when you play a cassette, you should clean the video heads.



1. During playback, press the MENU button.
2. Select the line 'PLAY FUNCTIONS' with the ▼ or ▲ button and confirm with the ▶ button.
3. Select the line 'HEAD CLEANING' with the ▼ or ▲ button.
4. Press the OK button. 'HEAD CLEANING IN PROGRESS' appears on the screen.
5. Wait a few seconds, until the message disappears and then press the MENU button.

6. MANUAL RECORDING

UK

Use 'Manual Recording' to make a spontaneous recording (for example, a programme currently being shown).

- ☐ If you want to start and stop a recording manually, read the section: 'Recording without automatic switch-off'.
- ☐ If you want to start a recording manually but have it stopped automatically, read the section: 'Recording with automatic switch-off'.
- ☐ If you want a recording to be controlled automatically by a satellite receiver, read the section entitled 'Automatic recording from a satellite receiver'.

Recording without automatic switch-off

1 Insert a cassette.

i The cassette is being checked. Wait until the search symbol in the display has gone out. More information on the Tape Manager can be found in the chapter 'The Tape Manager (TM)'.

2 Use the PROG.+ or PROG.– button to select the programme number (or channel name) you want to record. On the display appears:



i Programme numbers 'E1' and 'E2' are for recording from other sources (through scart sockets EXT.1 AV 1 and EXT.2 AV 2). Programme number 'E3' is for recording from the front sockets VIDEO and L AUDIO R.

i Programme numbers 'AUX' and 'MIC' are for audio recordings (through sockets AUX IN L R and the microphone socket 'MIC.').

3 To start recording, press the RECORD/OTR● button on the remote control or RECORD● on the video recorder. On the display you will see:



4 Stop recording with the ■ button.

Recording with automatic switch-off (OTR one-touch-recording)

1 Put a cassette in the machine.

i The cassette is being checked. Wait until the search symbol in the display has gone out.

2 Use the PROG.+ or PROG.– button to select the programme number (channel name) you want to record.

3 Press the RECORD/OTR● button on the remote control.

4 Press the RECORD/OTR● button again and again until the display on the video recorder shows the desired end time or length of the recording.

i To cancel this information, press the CLEAR (CL) button.

Protecting your recordings

So that you don't accidentally delete an important recording, remove the special tab on the narrow side of the cassette with a screwdriver or slide the special tab to the left. Later, if you no longer want to protect your recording, you can seal the gap again with sticky tape or slide the special tab to the right.

Auto-assembling

You can use the auto-assembling function to join individual recordings without any major picture disturbance between them.

1 While the cassette is playing, search for the correct position on the tape.

2 Stop the cassette by pressing the ■ button. '**II**' will appear in the display.

3 Now start recording as usual by pressing the RECORD/OTR● button on the remote control.

Selecting the recording speed (SP or LP)

You can reduce the recording speed by half. This makes it possible to record, for example, eight-hours instead of four-hours on an 'E240' (four-hour) cassette.

1. Switch on the TV set and, if required, select the programme number for the video recorder.
2. Press the MENU button. The main menu appears.
3. Select the line 'RECORDING FUNCTIONS' with the ▼ or ▲ button, and confirm with the ▶ button.
4. Select the line 'RECORD SETTINGS' with the ▼ or ▲ button, and confirm with the ▶ button.
5. Select the line 'RECORDING SPEED' with the ▼ or ▲ button.
6. Select the required recording speed with the ◀ or ▶ button.

   'LP': **L**ong **P**lay = half recording speed (double recording time).
   'SP': **S**tandard **P**lay = normal recording speed.

   The picture quality will be adversely affected when recording at half recording speed ('LP').

   For playback, the correct recording speed will automatically be selected.
7. Confirm with the OK button.
8. To end, press the MENU button.

Automatic recording from a satellite receiver (SAT RECORDING)

You can only use this function, when you have a satellite receiver, which can control other equipment by a 'programming' function through a scart cable.

1. Switch on the TV set. If required, select the programme number for the video recorder.
2. Press the MENU button. The main menu appears.
3. Select the line 'RECORDING FUNCTIONS' with the ▼ or ▲ button, and confirm with the ▶ button.
4. Select the line 'RECORD SETTINGS' with the ▼ or ▲ button, and confirm with the ▶ button.
5. Select the line 'SAT RECORDING' with the ▼ or ▲ button.
6. Select the required scart socket 'E1' or 'E2' with the ◀ or ▶ button.
   If you want to switch off the function, select 'OFF' with the ▶ or ◀ button.
7. Confirm with the OK button.
8. Use a scart cable to connect the scart socket you selected on the video recorder (EXT.1 AV 1 or EXT.2 AV 2) to the corresponding scart socket on the satellite receiver.
9. Insert a cassette.

   The cassette is being checked. Wait until the search symbol in the display has gone out.
10. Switch off with the STANDBY ⏻ button. The video recorder is now ready to record. The beginning and end of the recording is controlled via one of the scart sockets.

    When this function is switched on and the video recorder is switched off, '🔕' will appear on the video recorder display.

Switching on 'Direct Record'

When this function is switched on, the video recorder will automatically record the programme selected on the television by means of a scart cable.

> **The video recorder must be switched off** .

> With 'Connecting with scart cable and 'Easy Link/NexTView', the video recorder will also take the programme number from the TV set automatically with the video recorder switched on.

1. Switch on the TV set. If required, select the programme number for the video recorder.
2. Press the MENU button. The main menu appears.
3. Select the line 'RECORDING FUNCTIONS' with the ▼ or ▲ button, and confirm with the ▶ button.
4. Select the line 'RECORD SETTINGS' with the ▼ or ▲ button, and confirm with the ▶ button.
5. Select the line 'DIRECT RECORD' with the ▼ or ▲ button.
6. Select the function 'ON' with the ◀ or ▶ button. If you select 'OFF', the function will be switched off.
7. Confirm with the OK button.
8. To end, press the MENU button.
9. Switch off with the STANDBY ⏻ button.
10. On the TV set, select the programme number you want make the recording from.
11. Press the RECORD/OTR ● button with the video recorder **switched off**.

> Don't select another programme number on your TV set, until the 'search symbol' in the display of your video recorder disappears. This can take up to one minute.

> When 'NOTV' appears in the display, the programme number could not be found. The video recorder switches off automatically. In this case, read the section 'Recording without automatic switch-off'.

7. PROGRAMMED RECORDING (TIMER)

Use programmed recording to automatically start and stop a recording at a later date.

To make a programmed recording, your video recorder needs to know:

* the date you want to make the recording;
* the programme number for the TV channel you want to record;
* the start and stop time of the recording;
* VPS/PDC on or off
* the recording speed (SP/LP)

The video recorder stores all the information in a TIMER block. You can programme up to 6 TIMER blocks a month in advance.

'VPS' (Video Programming System) and 'PDC' (Programme Delivery Control)

With 'VPS and PDC', the TV station controls the start time and the length of the recording. This means that the video recorder switches itself on and off at the **right time** even if a TV programme you want to record begins earlier or finishes later than expected.
You must enter the start time **exactly to the minute**.
If you want to programme a time that is different from the VPS or PDC time, you must switch off VPS or PDC.

Programming a recording (with 'VIDEO Plus+')

All the information required for a programming is contained in the PlusCode-programming number.

VIDEO Plus+

1 Switch on the TV set and select the programme number for the video recorder.

2 Press the TIMER button on the remote control.
The programming mode selected last is marked.

3 Select the line 'VIDEOPLUS PROGRAMMING' with the ▼ or ▲ button and confirm with the ▶ button.

4 Enter the entire PlusCode-programming number (up to 9 digits) printed in your TV guide next to the start time of a TV programme.
For example, 5-234-89 or 5 234 89
Enter 523489 for the PlusCode-programming number.
If you make a mistake, you can clear your instructions with the CLEAR (CL) button.



5 Use the SELECT button to select daily or weekly programming.
'MO-FR': recordings every day from Monday to Friday.
'WEEKLY': recordings every week on the same day of the week.

6 Confirm with the OK button. Your programming details will then appear on the TV screen.



You need to confirm the programme number the first time you programme the video recorder with VIDEO Plus+.

If VIDEO Plus+ does not recognise the TV channel, 'PLEASE ENTER PROGRAMME NUMBER' will appear on the TV screen. Instead of 'PLEASE ENTER PROGRAMME NUMBER', you can select the programme number you want with the number buttons 0-9 and confirm with the OK button.

If 'VIDEO PLUS WRONG' appears on the TV screen, this means you entered an incorrect PlusCode number or the incorrect date. Correct your instructions or end with the TIMER button.

If 'WEEKEND PROGRAMMING - NOT POSSIBLE' appears on the TV screen, the date was incorrectly entered. 'Daily' programming can only be used for recordings to be made from Mondays to Fridays.

Use the SELECT button to switch 'VPS/PDC' on or off in 'START'.

Use the SELECT button to select the recording speed 'SP' or 'LP' in 'END'.

7 Confirm with the OK button when the information is correct.

The programming information has been stored in a TIMER block.

8 To end, press the TIMER button.

9 Make sure that the cassette you have put in can be recorded on.

The cassette is being checked. Wait until the search symbol in the display has gone out. More information on the Tape Manager can be found in the chapter 'The Tape Manager (TM)'.

10 Switch off with the STANDBY button.
The programmed recording will only function when the video recorder is **switched off** with the STANDBY button.

If any of the TIMER blocks are in use, '⏲' will light up on the video recorder display.

While a programmed recording is being made, you cannot operate your video recorder manually. If you want to cancel the programmed recording, press the STANDBY button.

If the video recorder is switched on a few minutes before a programmed recording is supposed to begin, 'SWITCH TO STANDBY - TIMER RECORDING' will flash on the TV screen.

If you reach the end of the cassette during a recording, the video recorder will automatically eject the cassette.

If you forget to load a cassette, 'NO CASSETTE' will appear on the TV screen and '⏲' will flash on the video recorder display.

If you have put in a cassette which cannot be used for recording, the video recorder will automatically eject it.

If 'TIMER FULL' appears on the TV screen when you press the TIMER button, you have used up all the available TIMER blocks. If you want to clear or check a TIMER block, select it with the PROG. + or PROG. − button.

Programme number 'AUX' and 'MIC' are provided for audio recordings (via sockets ' AUX IN L R ' and the microphone socket ' MIC. ').

Programming a recording (without 'VIDEO Plus+')

1 Switch on the TV set and select the programme number for the video recorder.

2 Press the TIMER button on the remote control.
The programming mode selected last is marked.

3 Select the line 'TIMER PROGRAMMING' with the ▼ or ▲ button and confirm with the ▶ button.



4 Select the entry field with the ◀ or ▶ button.

5 Enter information with the ▼ or ▲ button or with the digit buttons 0-9 .

Under 'DATE', use the SELECT button to select daily or weekly programming.
'MO - FR': Recording from Monday to Friday.
'MO': Recordings every week on the same day.

Under 'START', use the SELECT button to switch 'VPS or PDC' on or off.

Under 'END', use the SELECT button to select the recording speed 'SP' or 'LP'.

6 Confirm with the OK button when the information is correct.

The programming information has been stored in a TIMER block.

7 To end, press the TIMER button.

8 Make sure that the cassette you have put in can be recorded on.

The cassette is being checked. Wait until the search symbol in the display has gone out. More information on the Tape Manager can be found in the chapter 'The Tape Manager (TM)'.

9 Switch off with the STANDBY button.
The programmed recording will only function when the video recorder is **switched off** with the STANDBY button.

If any of the TIMER blocks are in use, '⏲' will light up on the video recorder display.

While a programmed recording is being made, you cannot operate your video recorder manually. If you want to cancel the programmed recording, press the STANDBY ⏻ button.

If the video recorder is switched on a few minutes before a programmed recording is supposed to begin, 'SWITCH TO STANDBY - TIMER RECORDING' will flash on the TV screen.

If you reach the end of the cassette during a recording, the video recorder will automatically eject the cassette.

If you forget to load a cassette, 'NO CASSETTE' will appear on the TV screen and '⏲' will flash on the video recorder display.

If you have put in a cassette which cannot be used for recording, the video recorder will automatically eject it.

If `TIMER FULL´ appears on the TV screen when you press the TIMER ⏲ button, you have used up all the available TIMER blocks. If you want to clear or check a programmed recording (TIMER block), press the ▶ button and select the TIMERR block with the PROG.+ or PROG.– button.

Programme numbers 'E1' and 'E2' are for recordings from other sources (through scart socket EXT.1 AV 1 or EXT.2 AV 2).

How to check or change a programmed recording (TIMER)

1. Switch on the TV set and select the programme number for the video recorder.
2. Press the TIMER ⏲ button on the remote control. The programming mode selected last is marked.
3. Select the line 'TIMER LIST' with the ▼ or ▲ button and confirm with the ▶ button.
4. Select the programmed recording (TIMER) you want to check or change with the PROG.+ or PROG.– button.
5. Press the ▶ button.
6. Select the entry field with the ◀ or ▶ button.
7. Change any information with the PROG.– or PROG.+ button or with the 0-9 buttons.

   Under 'END', use the SELECT button to select the recording speed 'SP' or 'LP'.
8. Confirm with the OK button.
9. To end, press the TIMER ⏲ button.
10. Make sure that the cassette you have put in can be recorded on. Switch off with the STANDBY ⏻ button.

    The programmed recording will only function when the video recorder is **switched off** with the STANDBY ⏻ button.

How to clear a programmed recording (TIMER)

1. Switch on the TV set and select the programme number for the video recorder.
2. Press the TIMER ⏲ button on the remote control. The programming mode selected last is marked.
3. Select the line 'TIMER LIST' with the ▼ or ▲ button and confirm with the ▶ button.
4. Select the programmed recording (TIMER) you want to clear with the ▼ or ▲ button.
5. Press the CLEAR (CL) button.
6. Confirm with the OK button.
7. Switch off with the TIMER ⏲ button.

'NexTView Link'

This video recorder is equipped with the function 'NexTView Link'. If your television is also equiped with this function, you can mark TV programmes on the television for programming. These TV programmes will automatically be transmitted to a TIMER block on the video recorder. If you clear the marking of the TV programme on the television, the corresponding TIMER block on the video recorder will also be cleared.
For more information, read the instruction manual of your TV set.

8. ADDITIONAL FUNCTIONS

UK

Changing the TV system

If you play back recordings made on a different kind of tape (for example, NTSC standard), the automatic TV system switch-over may lead to colour interferences. You can switch off the 'automatic TV system switch-over' as follows.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button. The main menu appears.

3 Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button and confirm with the ▶ button.



4 In the line 'TV SYSTEM' select the required TV system with the ◀ or ▶ button.

5 Confirm with the OK button.

6 To end, press the MENU button.

i If colour interference still occurs, you can switch to 'B/W' (black and white) in line 'TV SYSTEM'.

Child lock

This function will prevent unauthorised use of your video recorder. All button-functions will be locked.

i You can make programmed recordings while the child lock is on.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button. The main menu appears.

3 Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button and confirm with the ▶ button.



4 In the line 'CHILD LOCK' select 'ON' with the ◀ or ▶ button.

5 Confirm with the OK button.

6 To end, press the MENU button.
'🔒' appears in the video recorder display.
Keep the remote control in a safe place.

7 If you want to switch off the child lock, select 'OFF' in line 'CHILD LOCK'. '🔒' disappears from the video recorder display.

i If a button is pressed with activated child lock, '🔒' flashes in the display for a few seconds.

You may also activate the child lock with the remote control. Press the STANDBY ⏻ button on the remote control for a few seconds, until '🔒' appears in the video recorder display. Switch the child lock off in the same way.

Switching the 'on-screen display' (OSD) on or off

You can switch the on-screen display of the current operating information on or off.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button. The main menu appears.

3 Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button and confirm with the ▶ button.



4 Select the line 'OSD MODE' with the ▼ or ▲ button.

5 Select one of the options indicated with the ▶ or ◀ button.
'AUTO.': OSD information appears for a few seconds each time an operating mode is selected and then disappears.
'OFF': OSD information is switched off.
'ON': OSD information is switched on.

6 Confirm with the OK button.

7 To end, press the MENU button.

With the OK button you can superimpose the on-screen display of current operating mode on the TV screen.

Switching to 16:9 wide screen picture

If you are using a cassette with 16:9 wide screen recordings, you can switch this function 'ON'. The TV set will now automatically switch to wide screen. This only works if you have connected the TV set and the video recorder with a scart cable and if your TV set is suitable for wide screen.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button. The main menu appears.

3 Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button and confirm with the ▶ button.

4 If you have a TV set in wide-screen format, select 'ON' in line '16:9 WIDE SCREEN'. If not, select 'OFF'.

5 Confirm with the OK button.

6 To end, press the MENU button.

Switching the remote control command

If you have two video recorders with the same remote control command, you can change the remote control command of the handset and the remote control command of one of the video recorders.

1 Switch on the TV set. If required, select the programme number for the video recorder.

2 Press the MENU button. The main menu appears.

3 Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button and confirm with the ► button.



4 Select the line 'VCR 1 OR 2' with the ▼ or ▲ button.

5 Select 'VCR 1' or 'VCR 2' with the ◄ or ► .

6 Confirm with the OK button.

7 On the remote control, press the SELECT button and the digit button 2 **at the same time** to switch the remote control to 'VCR 2'.

i If you want to switch back to 'VCR 1, press the SELECT button and the digit button 1 **at the same time**.

8 Confirm with the OK button.

i If the menu does not disappear, the video recorder didn't recognise the remote control command. Repeat step 7 .

i After you changed the batteries in the remote control, it will switch back to 'VCR 1'.

i If e.g.: 'VCR ONLY RESPONDS TO VCR 2 COMMANDS' appears on the TV screen or 'VCR 2' appears in the video recorder display after pressing a button for a few seconds, you must switch the remote control to 'VCR 2'.

9 To end, press the MENU button.

Continuous playback

You can automatically play a cassette again and again. When the video recorder reaches the end of the tape or the end of the recording, it will rewind and start again.

1 Press the MENU button. The main menu appears.

2 Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button. Confirm with the ► button.



3 Select the line 'REPEAT PLAY' with the ▼ or ▲ button.

4 Select 'ON' with the ◄ or ► button. If you select 'OFF', the function will be switched off.

5 Confirm with the OK button.

6 Press the MENU button.

7 Put a cassette in the machine.

i The cassette is being checked. Wait until the search symbol in the display has gone out. More information on the Tape Manager can be found in the chapter 'The Tape Manager (TM)'.

8 Start the continuous playback with the ► playback button.

Automatic switch-off (tuner mode)

If you do not use the video recorder for a few minutes in certain modes (e.g.: STOP), it will switch to standby automatically. You can cancel this function to use the video recorder as a television receiver (tuner).

1. Switch on the TV set and select the programme number for the video recorder.
2. Press the MENU button. The main menu appears.
3. Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button and confirm with the menu button ►.
4. Select the line 'AUTO STANDBY' with the ▼ or ▲ button.
5. Select 'OFF' with the ◄ or ► button. If you select 'ON', the function will be switched on.
6. Confirm with the OK button.
7. To end, press the MENU button.

   A **TIMER recording** only works when the video recorder is **switched to standby**.

The 'DEMO' function

When the 'DEMO' function is switched on and the video recorder **switched off**, several menus will be demonstrated on the TV screen. This has no influence on operating the video recorder.

1. Switch on the TV set and select the programme number for the video recorder.
2. Press the MENU button. The main menu appears.
3. Select the line 'SPECIAL SETTINGS' with the ▼ or ▲ button and confirm with the ► button.
4. In the line 'DEMO', select 'ON' with the ► or ◄ button. If you select 'OFF' the function will be switched off.
5. Confirm with the OK button.
6. To end, press the MENU button.

   The 'DEMO' function is not possible during a 'TIMER recording' and during an 'Automatic recording from a satellite receiver'.

Switching off the button illumination

You can switch off the button illumination on the front of the machine.

1. Make sure there is **no** cassette in the machine. Press the PLAY► and PROGRAMME▲ buttons on the video recorder **at the same time** with the video recorder **switched off** until 'OFF' appears in the display.
2. To end, by pressing STANDBY ⏻.

   To switch this function back on repeat step 1 until 'ON' appears in the display.

Reducing picture disturbance ('optimizing the modulator')

You may experience picture disturbance if you have not used a scart cable to connect your video recorder and TV. This is because another TV station in your reception area may already be using UHF-channel CH35 or 583MHz.

1 Make sure that there is **no** cassette in the video recorder. On the video recorder, **simultaneously** hold the EJECT▲ and the PROG.– button for a few seconds until e.g.: 'CH35' or '583' appears in the display. The video recorder will transmit a test picture on UHF-channel 35(or frequency 583Mhz).



2 In line 'CHANNEL/FREQ.' select the indication for channel 'CH' or frequency 'FREQ.', using the ▶ or ◀ button.

3 Select the line 'OPTIMIZE' with the ▲ or ▼ button. Press the ▶ button.

4 When the video recorder finds a 'free' TV channel, the channel or frequency will be indicated.

> You can also enter the channel or frequency directly with the digit buttons 0-9.

5 Tune in the TV set in this channel or frequency.

6 Confirm the channel or frequency indicated with the OK button.

7 To end, press the MENU button.

Switching off the modulator

If you cannot clear picture or sound interference, you can switch off the built-in modulator. You should only do this if you have connected the video recorder to the TV set with a scart cable. 'Connecting VCR without scart cable' is not possible when the modulator is switched off.

> With the function 'Easy Link/NexTView' the modulator will be switched off automatically.

1 Switch on the TV set and select the programme number for the video recorder.

2 Make sure that **no** cassette is in the video recorder. On the video recorder, press the EJECT▲ and PROG.– button **at the same time** for several seconds, until, for example, 'CH35' or '583' appears on the video recorder display.

3 Select the line 'MODULATOR' on the TV screen or 'M ON' in the display with the ▲ or ▼ button.

4 With the ◀ or ▶ button, select the function 'OFF' on the TV screen or 'MOFF' (modulator off) in the display. Select 'ON' on the TV screen or 'M ON' (modulator on) in the display to switch the modulator back on.

5 Confirm with the OK button.

6 To end, press the MENU button.

Using your video recorder remote control with your TV set

Your video recorder remote control can transmit several commands to TV sets of different makes.
By using the **TV** buttons on the panel in the middle of the control, you can:

- [TV +] the TV volume up
- [TV −] the TV volume down
- [TV 🔇] switch off sound
- [TV ⏻] switch off the TV set
- [TV AV] switch the TV to AV
- [TV +] next programme number
- [TV −] previous programme number

1. Point your remote at the TV.
2. Hold the [TV ⏻] button and **at the same time** enter the correct remote control command with the digit buttons [0-9].

   If the selected code does not work with your TV set, or if the make of your TV is not in the list, you can try out the codes one after the other.

Manual audio control

With the [MANUAL] button you can switch to manual audio control.

1. Press the [MANUAL] button on the video recorder. The current selection appears in the display.
2. Keep pressing the [MANUAL] button until 'MAN' (manual audio control) appears in the display.
3. With the [PROGRAMME ▲] and [PROGRAMME ▼] buttons on the video recorder adjust the recording level so that the '0 dB' mark lights up during the loudest parts of the recording.

   At step 2 you can switch back to 'AUTO.' (automatic audio control) with the [MANUAL] button.

Recording audio only

You can use your video recorder as a HiFi tape recorder. You can record the sound from e.g. a HiFi unit or a second video recorder.

1. Switch on the TV set and select the programme number for the video recorder.
2. Put a cassette in the machine.

   For this function, use a cassette whose number is not stored in the Tape Manager (TM). More information on removing the cassette number from the TM can be found in the chapter 'The Tape Manager (TM)'.
3. Use the audio cable (cinch cable) supplied to connect your HiFi (stereo) unit with the [AUX IN L R] socket at the back of the video recorder.

   You can also use the [EXT.1 AV 1] or [EXT.2 AV 2] sockets or the front [L AUDIO R] sockets for audio-only recordings.

   You can also use the [EXT.1 AV 1] or [EXT.2 AV 2] sockets, the [MIC.] microphone socket or the audio front sockets for audio-only recordings.
4. Select the programme number from which the 'only audio' recording should be made, using the [PROG. +] or [PROG. −] button (e.g.: 'AUX' for the [AUX IN L R] socket.
5. Press the [MENU] button. The main menu appears.
6. Select the line 'RECORDING FUNCTIONS' with the [▼] or [▲] button and confirm with the [▶] button.
7. Select the line 'AUDIO ONLY' with the [▼] or [▲] button and confirm with the [▶] button.
8. To start sound recording, press the [RECORD/OTR ●] button.
9. To stop recording, press the [■] button.
10. To end, press the [MENU] button.

Audio dubbing

This function enables you to replace (dub) the sound track of an existing recording with another sound track. To do this, connect an audio source (e.g.: a CD-player) to one of the input sockets (for example, L AUDIO R). You can also connect a microphone to the MIC. socket (programme number 'MIC').

1 Switch the television on and select the channel number for the video recorder.

2 Put the cassette for dubbing in the machine.

i For this function, use a cassette whose number is not stored in the Tape Manager (TM). More information on removing the cassette number from the TM can be found in the chapter 'The Tape Manager (TM)'.

3 Press the MENU button. The main menu appears.

4 Select the line 'RECORDING FUNCTIONS' with the ▼ or ▲ button and confirm with the ▶ button.

5 Select the line 'AUDIO DUBBING' with the ▼ or ▲ button and confirm with the ▶ button.

6 Select the programme number for the audio source (e.g.: 'E3'). Switch on the external audio source.
During playback, locate the position on the tape at which the audio dubbing is to end.

7 Press the STILL/JOG ON ▶◀ button. 'STILL' appears on the TV screen.

8 Press the CLEAR (CL) button. '0:00:00' appears on the TV screen.

9 Locate the position at which the audio dubbing is to start.

10 Press the STILL/JOG ON ▶◀ button. 'STILL' appears on the TV screen.

11 Press the ■ button.

12 Press the RECORD/OTR ● button. The video recorder will start to record the sound transmitted from the audio source.
The audio recording stops **automatically** when the counter reaches '0:00:00'.

i The normal (linear) sound track is re-recorded, the stereo sound will remain.

13 To end audio dubbing,press the MENU button.

i To play back the dubbing sound track, read the next section 'Selection the sound track'.

Selecting the sound track

You can select the required sound track. This is of particular interest when the audio transmissions are multilingual.

1 Press the SELECT button. The current setting will appear on the TV screen.

2 By pressing the SELECT button several times you can select from the five possibilities displayed ('STEREO', 'RIGHT', 'LEFT', 'MONO', 'MIXED').

i Dubbed sound recordings can be replayed with the 'MONO' or 'MIXED' setting.
'MONO': Dubbed (linear) sound track.
'MIXED': Original sound (hi-fi sound track) together with dubbed sound (linear sound track).

i If the cassette does not have stereo sound recorded on it, the video recorder will automatically switch to mono.

Headphones volume

You can change the volume of the headphones connected.

1 During playback, press the MENU button. The main menu appears.

2 Select the line 'PLAY FUNCTIONS' with the ▼ or ▲ button and confirm with the ▶ button.

3 Select the line 'HEADPHONE VOLUME' with the ▼ or ▲ button and confirm with the ▶ button.

4 Adjust the volume with the ◀ or ▶ button.

5 Confirm with the OK button.

6 To end, press the MENU button.

Synchronous editing (synchro-edit)

You can synchronously copy between this video recorder and an appropriately equiped camera recorder. Both units are started at the same time with the help of a synchronous impulse and an adjustable start delay (=preroll time).

Connecting the video recorder and the camera recorder.

1. Connect the two units with a synchro-edit cable (socket SYNCHRO EDIT on the left front of the video recorder). Connect the video/audio source to the input sockets L AUDIO R and VIDEO (programme number 'E3') of the video recorder.
   Please also observe the instruction manual of the camera recorder.
2. Switch on the TV set. If required, select the programme number for the video recorder.
3. Press the MENU button. The main menu appears.
4. Select the line 'RECORDING FUNCTIONS' with the ▼ or ▲ button and confirm with the ► button.
5. Select the line 'CAMERA LINK' with the ▼ or ▲ button.
6. Switch the **camera recorder** to **'still picture'** (playback-pause).
7. Confirm with the ► button. The video recorder now checks the connected camera recorder type.

☐ The following message appears on the TV screen: 'VIDEO RECORDER TO CONTROL CAMERA' when the video recorder controls the camera recorder or 'CAMERA TO CONTROL VIDEO RECORDER' when the camera recorder controls the video recorder.

Starting synchro-edit

1. Switch on the TV set. If required, select the programme number for the video recorder.
2. Put a cassette in the machine.

   For this function, use a cassette whose number is not stored in the Tape Manager (TM). More information on removing the cassette number from the TM can be found in the chapter 'The Tape Manager (TM)'.
3. Press the MENU button. The main menu appears.
4. Select the line 'RECORDING FUNCTIONS' with the ▼ or ▲ button and confirm with the ► button.
5. Select the line 'SYNCHRO EDIT' with the ▼ or ▲ button and confirm with the ► button.
6. The OSD corresponding to the connected camera recorder type appears on the TV screen.
7. Search the beginning of the recording on the video recorder.
8. Press the STILL/JOG ON ▶|◀ button. 'STILL' appears on the TV screen.
9. Use the SELECT button to select the OSD for the camera recorder.
10. Search the beginning of the recording on the camera recorder.
11. Switch the camera recorder to 'still picture' (playback-Pause).

The way copying is started depends on the camera recorder type used:
Variant 1: when the video recorder controls the camera recorder, or
Variant 2: when the camera recorder controls the video recorder.

Variant 1, the video recorder is to control the camera recorder

1 Start copying with the RECORD/OTR● button on the video recorder.
The camera recorder starts 'PLAYBACK' and at the same time the video recorder starts 'RECORDING'.

2 Stop copying with the ■ button on the video recorder.

3 End copying with the MENU button.

Variant 2, the camera recorder is to control the video recorder

1 Start copying with the corresponding button on the camera recorder.
The camera recorder starts 'PLAYBACK' and at the same time the video recorder starts 'RECORDING'.

2 Stop copying with the PAUSE or STILL button on the camera recorder.

3 End copying with the MENU button.

Setting the 'preroll time'

When the beginning of the recording is missing, the 'preroll time' was too long. Select a shorter 'preroll time'.
If recording started too early, the 'preroll time' was too short. Select a longer 'preroll time'. You can select a 'preroll time' between 1:00 and 5:00 seconds.

1 Press the MENU button.

2 Select the line 'RECORDING FUNCTIONS' with the ▼ or ▲ button and confirm with the ► button.

3 Select the line 'RECORD SETTINGS' with the ▼ or ▲ button and confirm with the ► button.

4 In line 'PREROLL TIME', adjust the 'preroll time' with the ► or ◄ button.

i You can also directly enter the 'preroll time' with the digit buttons 0-9.

i With the CLEAR (CL) button you can reset the 'preroll time' to that of the identified camera recorder type.

5 Confirm with the OK buton.

6 To end, press the MENU button.

9. Before you call an engineer

If, contrary to expectation, you have any problems using this video recorder, it may be caused by one of the reasons mentioned below. You can also call the **customer service centre** in your country.
You will find the phone number in the enclosed guarantee leaflet.

Your video recorder does not respond to any button being pressed:
- There is no power supply: check the power supply
- A programmed recording is currently being made: cancel the programmed recording with the STANDBY ⏻ button.
- Child lock is on: switch the child lock off.
- There is a technical problem: switch off the mains power supply for 30 seconds, then switch it on again. If this does not have any effect, you can:
  1. Switch off the mains power supply again.
  2. Then switch it on **whilst holding down** the STANDBY ⏻ button on the video recorder.
  3. Release the button when 'OSD' appears on the video recorder display. All the information stored (TV channels, time and date, TIMER) will be cleared.

Cassette is jammed in the video recorder:
- Don't use force. Pull out the mains plug for a moment.

Remote control does not work:
- Remote control not pointed toward the video recorder: point it at the video recorder.
- Batteries have run out: change the batteries.
- You have given the wrong remote control command: read 'Switching remote control command' in chapter 'Additional functions'.

No picture when you play a cassette:
- There is no recording on the cassette: change the cassette.
- You have chosen the wrong programme number on the TV for playing cassette: on the TV, select the correct programme number for the video recorder.
- The cable connecting the TV set and the video recorder has come loose: check the cable.

Poor picture quality when you play a cassette:
- Your TV set is not properly adjusted.
- The cassette badly worn or of poor quality: use new cassette.
- Tracking is not properly adjusted or the video heads are dirty: turn to chapter 'PLAYBACK' and read the section 'Cleaning the video heads'.
- Read the section 'Selecting the picture setting (SMART PICTURE)', or 'Eliminating picture interference'.

The video recorder will not record:
- The TV channel you want to record is not stored or you selected the wrong programme number: check TV channels stored.
- You have loaded a cassette which cannot be recorded on: undo the erase protection on the cassette.

Programmed recording does not work:
- You have not set the TIMER properly: check the TIMER blocks.
- You have programmed the wrong time or date: check time and date.
- You have put in a cassette that cannot be recorded on: undo the erase protection on the cassette.
- After a 'programmed recording with 'VIDEO Plus+' the programme number of the TIMER block will not agree with the required programme number: when you have confirmed the PlusCode programming number, confirm the TIMER block by pressing the TIMER ⏻ button. Then change the programme number displayed in the 'PROG.' entry field and confirm by pressing the TIMER ⏻ button.

There is picture or sound interference on TV reception:
- Turn to chapter 'ADDITIONAL FUNCTIONS' and read 'Poor TV reception - optimising the modulator' and 'Switching off the modulator'.
- Have your aerial checked.

10. GLOSSARY

UK

Technical terms used

Current tape position : The part of the tape currently being played.
External source : A device connected via a socket (for example, scart socket) which is transmitting audio/video signals to the video recorder.
Index marking : A marking which is automatically made on the tape at the beginning of every recording. This marking (recording ID) can be searched for with the Index search function.
Scart cable : Also known as a Euro-AV cable. This standard cable is an easy method of connecting various audio and video devices, computer screens and televisions. Other signals in addition to audio and video signals can be transmitted on it.
TV system : There are various systems for transmitting television signals, for example, PAL, SECAM, PAL BG, SECAM DK, SECAM L/L, NTSC etc. The system used by your television depends on which country you are in.
TXT : Also known as Teletext, Fasttext, Videotext, FLOF etc.
OTR : One touch recording. This function enables you to select the switch-off time in intervals of 30 minutes.
Modulator : An electronic component in a video recorder which allows audio and video signals to be transmitted via the aerial cable. Your television receives the signal in the same way as a signal from a television station.
Modulator frequency : This frequency or channel indicates the frequency or channel on which the audio or video signal is transmitted.
UHF frequency range : Channels 21 to 69. The video recorder 'broadcasts' on channel 36/frequency 591 MHz. This frequency or channel can be changed. See the section 'Reducing picture disturbance ('optimizing the modulator').
OSD (On-screen display) : The largest possible display area for the video recorder - the screen on your television set.

Remote codes

UK

Brandt	21
Emerson	14
Ferguson	31
Finlux	33
Funai	35
GoldStar	04
Graetz	30
Grundig	24, 25
Hitachi	12
ITT	30
JVC	05, 27, 28, 29
Luxor	30
Magnavox	01, 02, 03
Mitsubishi	13, 26
Mivar	32
NEC	36
Nokia	34
Nordmende	21
Panasonic	07, 17, 19, 20
Philips	01
RCA	10
Saba	21
Salora	30
Samsung	01, 18, 37, 38, 39
Sanyo	11
Seleco	30
Sharp	16
Sony	09
Telefunken	21
Thomson	21, 22, 23
Toshiba	08
Zenit	06, 15

VR900/07

3103 166 23252
9202/010